


# NVR1 Parts Diagram



Ref No.	Part No.	Description
1	VR01001	Stem Assy
2	VR01002	Nut
3	VR01003	O-Ring
4	VR01004	Check Ring
5	VR01005	O-Ring
6	VR01006	O-Ring
7	VR01007	Round Pin
8	VR01008	Connector
9	VR01009	Lid
10	VR01010	Screw
11	VR01011	Knob
12	VR01012	Check Valve Assy
13	VR01013	Strip
14	VR01014	Check Ring
15	VR01015	5/16" Nut
16	VR01016	5/16" Cap
17	VR01017	Valve Core
18	VR01018	O-Ring
19	VR01019	Cap
20	VR01020	Strip
21	VR01021	O-ring