


# NP2DLM Parts Diagram



Ref No.	Part No.	Description
1	P02001	Oil Sump
2	P02002	Handle Assy
3	P02003	O-ring (Oil Sump)
4	P02004	Pump Cylinder Assy
5	P02005	Key
6	P02006	O-ring
7	P02007	O-ring
8	P02008	O-ring (Oil Fill Cap)
9	P02009	Oil Fill Cap
10	P02010	Trestle
11	P02011	Stator
12	P02012	3/8" Cap
13	P02013	Inlet Port
14	P02014	1/4" Cap
15	P02015	Rotor
16	P02016	Nut
17	P02017	Fan Blade
18	P02018	Rear Cover Assy
19	NB1/NBP2	5.0Ah/9.0Ah Battery Pack
20	P02020	Base Plate
21	P02021	Controller Assy
22	P02022	Cover Plate
Not Shown	P02023	Carrying Bag
Not Shown	NC1	Charger
Not Shown	NKR-2DL	Pump Rebuild Kit
Not Shown	RC16038	Oil Drain Cap