


# NRD16T Parts Diagram



Ref No.	Part No.	Description
1	320220101	Motor paper washer
2	320050101	Coupling element
3	300281601	Seal
4	300310072	O-ring
5	300310137	O-ring
6	320110205	Spring
7	300310074	O-ring
8	300280901	Seal
9	320510101	Anti-siphon plate
10	300310073	O-ring
11	320340101	Intake filter
12	300310070	O-ring KF25
13	320110302	Spring
14	320230101	Front gasket
15	300310079	Housing O-ring
16	320210101	Front gasket
17	300280602	Seal
18	320110104	Rotary vane spring
19	320100101	Fore rotary vane
20	320240101	Displacing valve
21	310080301	Spring
22	311150103	Gas ball valve head
23	320100201	Back vane
24	320200101	Exhaust port paper board
25	300310081	O-ring
26	320160101	Oil sight O-ring
27	320170101	Oil sight
28	320190101	Sight glass washer
Not Shown	310493501	Start Capacitor
Not Shown	310492801	Run Capacitor
Not Shown	320450201	Back Cover
Not Shown	NSK16	Pump Rebuild Kit