


NP12DA1 Parts Diagram



REF No	Part No.	Description
1	P012001	Oil Lens Cover
2	P012002	Oil Lens
3	P012003	O-ring of Oil Lens
4	P012004	Oil Housing
5	P012041	Outlet Gasket
6	P012042	Outlet KF25
7	NF43	Exhaust Filter and Noise Reducer
8	P012006	Pump Body
9	P012007	Coupling
10	P012008	Gasket
11	P012009	O-ring of Oil Housing
12	P012010	Trestle
13	P012011	Gas Ballast Assy
14	P012012	Handle
15	P012013	Hook
16	P012014	Nut
17	P012043	Inlet KF25
18	P012020	O-ring of Inlet Port
19	P012021	Anti suckback valve plate
20	P012022	Anti suckback valve cap
21	P012023	Anti suckback piston assy
22	P012024	Anti suckback spring
23	P012025	Top Cover
24	P012026	Capacitor
25	P012027	Capacitor hook
26	P012028	Rear Cover Assy
27	P012029	Elastic Collar
28	P012030	Fan
29	P012031	DC Motor Assy
30	P012032	Coupling
31	P012033	Guard Board I
32	P012034	Guard Board II
33	P012035	Sheath
34	P012036	Rubber Gasket
35	P012037	Base Plate
36	P012038	Rubber Feet
37	P012039	Controller Assy
38	P012040	Cover Plate
Not Shown	NPS225	KF25 Clamp & O-Ring