


NX1



Ref No.	Part No.	Description
1	NX1001	Knob cover
2	NX1002	Knob Assy
3	NX1003	Front cover assembly
4	NX1004	Transparent window
5	NX1005	Control Keys
6	NX1006	PCB
7	NX1007	Battery pressing plate
8	NX1008	Li-battery
9	NX1009	Fixed block assembly
10	NX1010	Back cover assembly
11	NX1011	Rubber plug
12	NX1012	Foldable Hook assembly
13	NX1013	Cable clip
14	NX1014	Sensor Assembly
15	NX1015	O-ring
16	NX1016	Valve Assembly